

## Effisus Stopper System



**1**

- Make sure that all surfaces are properly clean and dry
- Cut Multishapper membrane according to our chart guide
- Shape it into desired geometry



**2**

- Place Multishapper curb around penetration (distance  $\geq 25$  mm)
- Mark the exterior perimeter
- Remove the curb and set it aside



**3**

- Use Effisus M-1 Sealant to:
  - Seal the base of the penetration
  - Coat penetration surface up to 75 mm
  - Apply a 8mm bead to curb bottom



**4**

- Position the Multishapper curb and press it down firmly
- Insert the metal clip
- Apply a bead of M-1 to seal interior edges of the clip
- Pour the 1-P Sealant and fill the curb up to the top